

SIM2 Multimedia

SUPERLUMIS

RS-232 Control

Rev. 1.0 (01 April 2014)



Contents

Contents	2
1. Introduction	3
1.1. Setting up the RS-232C Serial connection	3
1.2. Execution of the command	4
2. Commands	
2.1. Remote Control Keys Codes	5
2.2. Operation Commands	6
2.3. Status Commands	11
3. Examples	14

Revision History

Rev.	Date	Software Version	Description of Change
1.0	01 April 2014	5.00.18 or higher	Initial version.

1. Introduction

This document describes how to interface the SUPERLUMIS projector with a Home Theatre control system (or a PC) over a direct serial connection.

1.1. Setting up the RS-232C Serial connection

Follow these steps to configure the control system (or the PC) serial port.

- Switch off the control system (or the PC) and the projector.
- Use a standard straight¹ serial cable with 9 pin female to the control system (or the PC) and 9 pin male to the Projector:

RS-232C Control Port			
	Pin No	Signal	Definition
	1	-	Not Used
	2	TD	Transmit Data
	3	RD	Receive Data
	4	-	Not Used
	5	GND	Ground
	6	-	Not Used
	7	-	Not Used
	8	-	Not Used
	9	-	Not Used

- Make sure the distances between equipment do not exceed the specifications of the interface (15 m or 50 feet).
- Switch on the control system (or the PC) and, after start up, switch on the projector.
- Set the Serial Port Parameters as shown below:

Communication Parameters	
Parameter	Value
Transfer Rate	19200 bps
Data Bits	8
Parity Bit	None
Stop Bit	1
Flow Control	None

- Set the control system (or the PC program) Communication Mode to Binary (or Hex). ASCII mode is not supported.
- Set the control system interface (or the PC communication program) Display Mode to Hex.

¹A cable that connects identical pin numbers in each connector: pin 2 connects to pin 2, pin 3 to pin 3 and pin 5 to pin 5.

1.2. Execution of the command

Command execution time may vary from 0.1 to 2.0 seconds, depending on the operation that have been requested. If the projector is busy when a command is sent, the unit may not accept the command. When several commands are to be sent one after the other, sufficient time between them should be allowed. When the unit is switched on from Standby wait 15 seconds before sending commands or reading messages sent by the projector.

2. Commands

In this section, serial commands (and respective responses) are listed. Commands (and responses) are series of bytes (numbers holding values from 0 to 255).

In the following, bytes are represented by couples of hexadecimal digits, shown in monospace (fixed-width) type (for example: EF¹). Spaces between bytes (for example: E4 48) have been inserted just to make the command more readable and are not part of the command itself.

Commands do not require any termination character: do not add <LF>, <CR>, <EOT> or the like at the end of the given series of bytes.

2.1. Remote Control Keys Codes

The following serial commands are meant to emulate button presses on the SUPERLUMIS IR Remote Control. Like remote button presses they interact with the OSD of the projector.

Key	Command
Standby	BE EF 02 06 00 51 E4 48 01 00 00 00 00
0/On/Input	BE EF 02 06 00 6B E6 52 01 00 00 00 00
1	BE EF 02 06 00 80 E5 49 01 00 00 00 00
2	BE EF 02 06 00 B3 E5 4A 01 00 00 00 00
3	BE EF 02 06 00 62 E4 4B 01 00 00 00 00
4	BE EF 02 06 00 D5 E5 4C 01 00 00 00 00
5	BE EF 02 06 00 04 E4 4D 01 00 00 00 00
6	BE EF 02 06 00 37 E4 4E 01 00 00 00 00
7	BE EF 02 06 00 E6 E5 4F 01 00 00 00 00
8	BE EF 02 06 00 89 E7 50 01 00 00 00 00
9	BE EF 02 06 00 58 E6 51 01 00 00 00 00
Select (●)	BE EF 02 06 00 BA E7 53 01 00 00 00 00
Esc	BE EF 02 06 00 0D E6 54 01 00 00 00 00
Arrow Up	BE EF 02 06 00 DC E7 55 01 00 00 00 00
Arrow Left	BE EF 02 06 00 EF E7 56 01 00 00 00 00
Arrow Right	BE EF 02 06 00 3E E6 57 01 00 00 00 00
Arrow Down	BE EF 02 06 00 C1 E6 58 01 00 00 00 00
Menu Left (-)	BE EF 02 06 00 10 E7 59 01 00 00 00 00
Menu Right (+)	BE EF 02 06 00 23 E7 5A 01 00 00 00 00
3D Menu ()	BE EF 02 06 00 F2 E6 5B 01 00 00 00 00
Memory	BE EF 02 06 00 45 E7 5C 01 00 00 00 00
F1	BE EF 02 06 00 94 E6 5D 01 00 00 00 00
F2	BE EF 02 06 00 76 E7 5F 01 00 00 00 00
Info	BE EF 02 06 00 A7 E6 5E 01 00 00 00 00
Auto	BE EF 02 06 00 79 E2 60 01 00 00 00 00
Aspect	BE EF 02 06 00 A8 E3 61 01 00 00 00 00

¹A variety of alternative conventions are used for representing hexadecimal digits, the most common being: Hex EF, EF₁₆, EFh, 0xEF.

Commands 1-9 perform different actions depending on the projector status:

Status	Command	Action
Standby	0	switches the unit on and selects the last input memorized prior to switch off
	1-5	switch the unit on and select corresponding input
	6-9	switch the unit on and select the last input memorized prior to switch off
On	0	displays the Input Selection window of the OSD
	1-5	when OSD is not displayed, select corresponding inputs

The response of the unit to a Remote Control Key Code depends on the projector status:

Status	Response	Action
Standby	06 3A 06	Command acknowledged (may be valid or invalid)
On	06	Valid command (acknowledged and validated)
	15 ..	Invalid command (acknowledged but not validated)

where bytes marked with .. are not relevant.

2.2. Operation Commands

On

The following commands switch the unit On and select the desired input at the same time. Selection of the Last Input (the one that was selected at the moment of the last switch off) is also possible.

Action	Command
Turn on and select last Input	BE EF 02 06 00 6B E6 52 01 00 00 00 00
Turn on and select Input 1	BE EF 02 06 00 80 E5 49 01 00 00 00 00
Turn on and select Input 2	BE EF 02 06 00 B3 E5 4A 01 00 00 00 00
Turn on and select Input 3	BE EF 02 06 00 62 E4 4B 01 00 00 00 00
Turn on and select Input 4	BE EF 02 06 00 D5 E5 4C 01 00 00 00 00
Turn on and select Input 5	BE EF 02 06 00 04 E4 4D 01 00 00 00 00

If the command is acknowledged, the response is:

06 3A 06

where bytes marked with .. are not relevant.

Unfortunately, it is not possible to distinguish a valid command from an invalid one, as the response is the same in both cases.

Off

Action	Command	Response
Off	BE EF 02 06 00 51 E4 48 01 00 00 00 00	OK 06
		Error 15 ..

Brightness

Action	Command	Response
Increment	BE EF 1A 0C 00 5E A3 00 00 02 00 00 00 00 00 00 00	OK 20 XX 00
Decrement	BE EF 1A 0C 00 9B F2 00 00 03 00 00 00 00 00 00 00	Error 15 ..
Get	BE EF 1A 0C 00 51 53 00 00 01 00 00 00 00 00 00 00	

In the response, XX is the hex representation of the value of Brightness.

Example: if the returned value is XX = 3C then Brightness value is 60.

Contrast

Action	Command	Response
Increment	BE EF 1A 0C 00 9D 5E 01 00 02 00 00 00 00 00 00 00 00 00 00 00	OK 20 XX 00
Decrement	BE EF 1A 0C 00 58 0F 01 00 03 00 00 00 00 00 00 00 00 00 00 00	Error 15 ..
Get	BE EF 1A 0C 00 92 AE 01 00 01 00 00 00 00 00 00 00 00 00 00 00	

In the response, XX is the hex representation of the value of Contrast.
 Example: if the returned value is XX = 3C then Contrast value is 60.

Color

Action	Command	Response
Increment	BE EF 1A 0C 00 5A A7 03 00 02 00 00 00 00 00 00 00 00 00 00 00	OK 20 XX 00
Decrement	BE EF 1A 0C 00 9F F6 03 00 03 00 00 00 00 00 00 00 00 00 00 00	Error 15 ..
Get	BE EF 1A 0C 00 55 57 03 00 01 00 00 00 00 00 00 00 00 00 00 00	

In the response, XX is the hex representation of the value of Color.
 Example: if the returned value is XX = 3C then Color value is 60.

Tint

Action	Command	Response
Increment	BE EF 1A 0C 00 99 5A 02 00 02 00 00 00 00 00 00 00 00 00 00 00	OK 20 XX 00
Decrement	BE EF 1A 0C 00 5C 0B 02 00 03 00 00 00 00 00 00 00 00 00 00 00	Error 15 ..
Get	BE EF 1A 0C 00 96 AA 02 00 01 00 00 00 00 00 00 00 00 00 00 00	

In the response, XX is the hex representation of the value of Tint.
 Example: if the returned value is XX = 3C then Tint value is 60.

Cinema Mode

Action	Command	Response
Set Off	BE EF 1A 0C 00 84 12 0C 00 00 00 00 00 00 00 00 00 00 00 00 00	OK 20 XX 00
Set Auto	BE EF 1A 0C 00 91 52 0C 00 00 00 03 00 00 00 00 00 00 00 00 00	03 Auto
Get	BE EF 1A 0C 00 41 43 0C 00 01 00 00 00 00 00 00 00 00 00 00 00	00 Off
		Error 15 ..

In the response, XX is the hex representation of the value of Cinema Mode.
 Example: if the returned value is XX = 03 then Cinema Mode value is Auto.

Pure Motion

Action	Command	Response
Set Off	BE EF 1A 0C 00 83 2B 5E 00 00 00 00 00 00 00 00 00 00 00 00 00	OK 20 XX 00
Set Low	BE EF 1A 0C 00 4F EA 5E 00 00 00 01 00 00 00 00 00 00 00 00 00	00 Off
Set Medium	BE EF 1A 0C 00 5A AA 5E 00 00 00 02 00 00 00 00 00 00 00 00 00	01 Low
Set High	BE EF 1A 0C 00 96 6B 5E 00 00 00 03 00 00 00 00 00 00 00 00 00	02 Medium
Get	BE EF 1A 0C 00 46 7A 5E 00 01 00 00 00 00 00 00 00 00 00 00 00	03 High
		Error 15 ..

In the response, XX is the hex representation of the value of PureMotion.
 Example: if the returned value is XX = 01, then PureMotion value is Low.

Dynamic Black (2D only)

Action	Command	Response	
Set Off	BE EF 1A 0C 00 07 AF 3D 00 00 00 00 00 00 00 00 00 00	OK	20 XX 00
Set Video	BE EF 1A 0C 00 CB 6E 3D 00 00 00 01 00 00 00 00 00 00 00		00 Off
Set Movie	BE EF 1A 0C 00 DE 2E 3D 00 00 00 02 00 00 00 00 00 00 00		01 Video
Get	BE EF 1A 0C 00 C2 FE 3D 00 01 00 00 00 00 00 00 00 00 00		02 Movie
		Error	15 ..

In the response, XX is the hex representation of the value of Dynamic Black.
Example: if the returned value is XX = 01 then Dynamic Black value is On.

Aspect

Action	Command	Response	
Set Normal	BE EF 02 06 00 2A F4 83 01 00 00 00 00	OK	06
Set Anamorphic	BE EF 02 06 00 9D F5 84 01 00 00 00 00	Error	15 ..
Set Letterbox	BE EF 02 06 00 4C F4 85 01 00 00 00 00		
Set Panoramic	BE EF 02 06 00 7F F4 86 01 00 00 00 00		
Set Subtitle	BE EF 02 06 00 62 F5 8B 01 00 00 00 00		
Set Pixel to Pixel	BE EF 02 06 00 AE F5 87 01 00 00 00 00		
Set User 1	BE EF 02 06 00 51 F5 88 01 00 00 00 00		
Set User 2	BE EF 02 06 00 80 F4 89 01 00 00 00 00		
Set User 3	BE EF 02 06 00 B3 F4 8A 01 00 00 00 00		

Color Management

Primaries

Action	Command	Response	
Set Native	BE EF 1A 0C 00 68 FE 41 00 00 00 00 00 00 00 00 00 00	OK	20 XX 00
Set HDTV	BE EF 1A 0C 00 A4 3F 41 00 00 00 01 00 00 00 00 00 00 00		00 Native
Set EBU	BE EF 1A 0C 00 B1 7F 41 00 00 00 02 00 00 00 00 00 00 00		01 HDTV
Set SMPTE-C	BE EF 1A 0C 00 7D BE 41 00 00 00 03 00 00 00 00 00 00 00		02 EBU
Set Auto	BE EF 1A 0C 00 9B FF 41 00 00 00 04 00 00 00 00 00 00 00		03 SMPTE-C
Get	BE EF 1A 0C 00 AD AF 41 00 01 00 00 00 00 00 00 00 00 00		04 Auto
		Error	15 ..

In the response, XX is the hex representation of the value of the Primaries adjustment.
Example: if the returned value is XX = 02 then Primaries value is EBU.

Note: LCC A and LCC B refer to Primaries values that the PC application LiveColorsCalibration downloads into the projector.

White Point

Action	Command	Response	
Set Standard	BE EF 1A 0C 00 B7 DE 39 00 00 00 0A 00 00 00 00 00 00 00	OK	20 XX 00
Set High	BE EF 1A 0C 00 C8 5E 39 00 00 00 00 00 00 00 00 00 00 00		0A Standard
Set Medium	BE EF 1A 0C 00 04 9F 39 00 00 00 01 00 00 00 00 00 00 00		00 High
Set Low	BE EF 1A 0C 00 11 DF 39 00 00 00 02 00 00 00 00 00 00 00		01 Medium
Set Native	BE EF 1A 0C 00 DD 1E 39 00 00 00 03 00 00 00 00 00 00 00		02 Low
Set D75	BE EF 1A 0C 00 44 DF 39 00 00 00 0E 00 00 00 00 00 00 00		03 Native
Set D65	BE EF 1A 0C 00 7B 1F 39 00 00 00 0B 00 00 00 00 00 00 00		0E D75
Set D50	BE EF 1A 0C 00 9D 5E 39 00 00 00 0C 00 00 00 00 00 00 00		0B D65
Set C	BE EF 1A 0C 00 51 9F 39 00 00 00 0D 00 00 00 00 00 00 00		0C D50
Set User	BE EF 1A 0C 00 3B 5F 39 00 00 00 04 00 00 00 00 00 00 00		0D C
Get	BE EF 1A 0C 00 0D 0F 39 00 01 00 00 00 00 00 00 00 00 00		04 User
		Error	15 ..

In the response, XX is the hex representation of the value of the White Point.
Example: if the returned value is XX = 0B then White Point value is D65.

Gamma

Action	Command	Response
Set Normal	BE EF 1A 0C 00 DC 4A 36 00 00 00 00 00 00 00 00 00 00	OK 20 XX 00
Set Dynamic	BE EF 1A 0C 00 10 8B 36 00 00 00 01 00 00 00 00 00 00	00 Natural
Set Param.	BE EF 1A 0C 00 05 CB 36 00 00 00 02 00 00 00 00 00 00	01 Dynamic
Get	BE EF 1A 0C 00 19 1B 36 00 01 00 00 00 00 00 00 00 00	02 Param.
		Error 15 ..

In the response, XX is the hex representation of the value of Gamma.

Example: if the returned value is XX = 02 then Gamma is set to Parametric.

Overscan

Action	Command	Response
Increment	BE EF 1A 0C 00 91 52 04 00 02 00 00 00 00 00 00 00 00	OK 20 XX 00
Decrement	BE EF 1A 0C 00 54 03 04 00 03 00 00 00 00 00 00 00 00	Error 15 ..
Get	BE EF 1A 0C 00 9E A2 04 00 01 00 00 00 00 00 00 00 00	

In the response, XX is the hex representation of the value of Overscan.

Example: if the returned value is XX = 0A then Overscan value is 10.

Lamp Power

Action	Command	Response
Set 290	BE EF 1A 0C 00 26 1C 25 00 00 00 22 01 00 00 00 00 00	OK 20 XX 01
Set 300	BE EF 1A 0C 00 AA 9d 25 00 00 00 2C 01 00 00 00 00 00 00	22
Set 310	BE EF 1A 0C 00 D9 1C 25 00 00 00 36 01 00 00 00 00 00 00	2C
Set 320	BE EF 1A 0C 00 D7 9B 25 00 00 00 40 01 00 00 00 00 00 00	36
Set 330	BE EF 1A 0C 00 A8 1B 25 00 00 00 4A 01 00 00 00 00 00 00	4A
Set 340	BE EF 1A 0C 00 28 9B 25 00 00 00 54 01 00 00 00 00 00 00	54
Set 350	BE EF 1A 0C 00 57 1B 25 00 00 00 5E 01 00 00 00 00 00 00	5E
Get	BE EF 1A 0C 00 E2 DE 25 00 01 00 00 00 00 00 00 00 00 00	Error 15 ..

In the response, YY XX is the hex representation of the value of Lamp Power.

Example: if the returned value is XX YY = 5E 01 then the Lamp Power value is 350W.

Variable Iris

Action	Command	Response
Set 0	BE EF 1A 0C 00 8B 23 58 00 00 00 00 00 00 00 00 00 00	OK 20 XX 00
Set 10	BE EF 1A 0C 00 F4 A3 58 00 00 00 0A 00 00 00 00 00 00 00	Error 15 ..
Set 20	BE EF 1A 0C 00 74 23 58 00 00 00 14 00 00 00 00 00 00 00	
Set 30	BE EF 1A 0C 00 0B A3 58 00 00 00 1E 00 00 00 00 00 00 00	
Set 40	BE EF 1A 0C 00 35 20 58 00 00 00 28 00 00 00 00 00 00 00	
Set 50	BE EF 1A 0C 00 46 A1 58 00 00 00 32 00 00 00 00 00 00 00	
Set 60	BE EF 1A 0C 00 CA 20 58 00 00 00 3C 00 00 00 00 00 00 00	
Set 70	BE EF 1A 0C 00 91 A7 58 00 00 00 46 00 00 00 00 00 00 00	
Set 80	BE EF 1A 0C 00 B7 26 58 00 00 00 50 00 00 00 00 00 00 00	
Set 90	BE EF 1A 0C 00 C8 A6 58 00 00 00 5A 00 00 00 00 00 00 00	
Set 100	BE EF 1A 0C 00 50 24 58 00 00 00 64 00 00 00 00 00 00 00	
Get	BE EF 1A 0C 00 4E 72 58 00 01 00 00 00 00 00 00 00 00 00	

In the response, XX is the hex representation of the status of the Variable Iris.

Example: if the returned value is XX = 5A then the Variable Iris value is 90.

3D Mode

Action	Command	Response
Set 2D	BE EF 1A 0C 00 48 DE 59 00 00 00 00 00 00 00 00 00 00	OK 20 XX 00
Set 3D	BE EF 1A 0C 00 84 1F 59 00 00 00 01 00 00 00 00 00 00	00 2D
Get	BE EF 1A 0C 00 8D 8F 59 00 01 00 00 00 00 00 00 00 00	01 3D
		Error 15 ..

In the response, XX is the hex representation of the status of the 3D Mode.

Example: if the returned value is XX = 01 then Mode is 3D.

3D Input Format

Action	Command	Response
Set Side by Side	BE EF 1A 0C 00 4C DA 5A 00 00 00 00 00 00 00 00 00 00	OK 20 XX 00
Set Top Bottom	BE EF 1A 0C 00 80 1B 5A 00 00 00 01 00 00 00 00 00 00	00 S-S
Set Frame Sequential	BE EF 1A 0C 00 95 5B 5A 00 00 00 02 00 00 00 00 00 00	02 F-S
Get	BE EF 1A 0C 00 89 8B 5A 00 01 00 00 00 00 00 00 00 00	01 T-B
		Error 15 ..

In the response, XX is the hex representation of the value of 3D Input Format.

Example: if the returned value is XX = 01 then 3D Input Format value is Top Bottom.

3D Left/Right

Action	Command	Response
Set Normal	BE EF 1A 0C 00 8F 27 5B 00 00 00 00 00 00 00 00 00 00	OK 20 XX 00
Set Swapped	BE EF 1A 0C 00 43 E6 5B 00 00 00 01 00 00 00 00 00 00	00 Normal
Get	BE EF 1A 0C 00 4A 76 5B 00 01 00 00 00 00 00 00 00 00	01 Swapped
		Error 15 ..

In the response, XX is the hex representation of the value of 3D Left/Right.

Example: if the returned value is XX = 01 then 3D Left/Right value is Swapped.

Lens Zoom – Focus Calibration

Action	Command	Response
Zoom -1	BE EF 10 0B 00 AF C9 00 01 00 01 01 20 00 00 00 02 FF	OK 1E BE EF 10 0D 00 3C C7 01 01 00 01 01 20 00 00 00 02 00 00 00
Zoom -10	BE EF 10 0B 00 A8 49 00 01 00 01 01 20 00 00 00 02 F5	1E BE EF 10 0D 00 3C C7 01 01 00 01 01 20 00 00 00 02 00 00 00
Zoom +1	BE EF 10 0B 00 AF C9 00 01 00 01 01 20 00 00 00 02 FF	1E BE EF 10 0D 00 3C C7 01 01 00 01 01 20 00 00 00 02 00 00 00
Zoom +10	BE EF 10 0B 00 E8 09 00 01 00 01 01 20 00 00 00 02 0A	1E BE EF 10 0D 00 3C C7 01 01 00 01 01 20 00 00 00 02 00 00 00
Focus +1	BE EF 10 0B 00 8F 4B 00 01 00 01 01 20 00 00 00 04 01	1E BE EF 10 0D 00 B4 C7 01 01 00 01 01 20 00 00 00 04 00 00 00
Focus +5	BE EF 10 0B 00 4C 4A 00 01 00 01 01 20 00 00 00 04 05	1E BE EF 10 0D 00 B4 C7 01 01 00 01 01 20 00 00 00 04 00 00 00
Focus -1	BE EF 10 0B 00 0F CA 00 01 00 01 01 20 00 00 00 04 FF	1E BE EF 10 0D 00 3C C7 01 01 00 01 01 20 00 00 00 02 00 00 00
Focus -5	BE EF 10 0B 00 0C 0A 00 01 00 01 01 20 00 00 00 04 FA	1E BE EF 10 0D 00 B4 C7 01 01 00 01 01 20 00 00 00 04 00 00 00
		Error 15 ..

Memories

Action	Command	Response
Memory 1 Recall	BE EF 02 06 00 A8 F2 A1 01 00 00 00 00	OK 20 XX 00
Memory 2 Recall	BE EF 02 06 00 9B F2 A2 01 00 00 00 00	Error 15 ..
Memory 3 Recall	BE EF 02 06 00 4A F3 A3 01 00 00 00 00	
Memory 4 Recall	BE EF 02 06 00 FD F2 A4 01 00 00 00 00	
Memory 5 Recall	BE EF 02 06 00 2C F3 A5 01 00 00 00 00	
Memory 6 Recall	BE EF 02 06 00 1F F3 A6 01 00 00 00 00	

2.3. Status Commands

Status Commands may be used to get the current value of the main projector parameters. Sections below describe the responses when the unit is On. It is not possible to receive a significant response when the unit is in Standby state.

Status Commands

Parameter	Command
Projector	BE EF 10 0A 00 34 B7 01 01 00 01 01 15 01 00 00 02
Status	
Signal Status	BE EF 10 0A 00 33 37 01 01 00 01 01 15 01 00 00 08
Lamp Status	BE EF 10 0A 00 A9 36 01 01 00 01 01 15 01 00 01 10

Projector Status

If the unit is On, the returned packet (27 byte long) is described in the following table:

1E	BE	EF	10	13	00	01	01	00	01	01	15	01	00	00	02	00	00	00	SS
0	1																17	18			20	21				

where bytes marked with .. are not relevant.

The response may be separated into 4 parts:

- 1 bytes (byte 0) that initiates the packet (1E)
- 17 bytes (bytes 1{17}) that duplicate the sent command (apart from 2 of them | the CRC)
- 3 Error bytes (bytes 18{20}) that signal errors in the processing of the command
- 1 Data byte (byte 21) that contains the requested data

If the 3 Error bytes (bytes 18{20}) are 00 00 00 then requested data are valid.

The table below explains the meaning of returned data.

- Byte 21 (labeled SS in the table above) contains Projector Status:

On	01
Lamp Ignition	02
Lamp Restrike	03
Lamp Cooling	04

Signal Status

When then unit is On, the returned packet (25 byte long) is described in the following table:

1E	BE	EF	10	11	00	01	01	00	01	01	15	01	00	00	08	00	00	00	SS	II
0	1																17	18			20	21				

where bytes marked with .. are not relevant.

The response may be separated into 4 parts:

- 1 bytes (byte 0) that initiates the packet (1E)
- 17 bytes (bytes 1{17}) that duplicate the sent command (apart from 2 of them | the CRC)
- 3 Error bytes (bytes 18{20}) that signal errors in the processing of the command
- 2 Data bytes (bytes 21, 24) that contain the requested data

If the 3 Error bytes (bytes 18-20) are 00 00 00 then requested data are valid.

The tables below explain the meaning of returned data.

- Byte 21 (labelled SS in the table above) contains current Input Status:

OK	00
No Signal	01
Signal Out of Range	02

- Byte 24 (labelled II in the table above) contains Current Input:

1	Video	00
2	YPrPb	04
	RGB	05
3	Graphics RGB	0C
	Graphics YPrPb	0D
4	HDMI 1	12
5	HDMI 2	13

Lamp Status

When the unit is On, the returned packet (27 byte long) is described in the following table:

1E	BE	EF	10	13	00	01	01	00	01	01	15	01	00	01	10	00	00	00	UU	UU	..	SS	LL	LL
0	1																17	18		20	21	22		24	25	26

where bytes marked with .. are not relevant.

The response may be separated into 4 parts:

- 1 bytes (byte 0) that initiates the packet (1E)
- 17 bytes (bytes 1{17}) that duplicate the sent command (apart from 2 of them | the CRC)
- 3 Error bytes (bytes 18{20}) that signal errors in the processing of the command
- 5 Data bytes (bytes 21{22, 24, 25{26}) that contain the requested data

If the 3 Error Bytes (bytes 18{20}) are 00 00 00 then requested data are valid.

The tables below explain the meaning of returned data.

- Bytes 21 and 22 (labelled **UU UU** in the table above) contain **Unit Working Hours**. UU UU is the hex representation of the number of working hours. Therefore, if, for instance, UU UU = 09 D8 then Unit Working Hours is 2520.

- Byte 24 (labelled **SS** in the table above) contains the **Lamp Status**:

Off	00
Ignition	01
On	02

- Bytes 25 and 26 (labelled **LL LL** in the table above) contain **Lamp Working Hours**. LL LL is the hex representation of the number of working hours. Therefore, if, for instance, LL LL = 01 B6 then Unit Working Hours is 438.

3. Examples

Send the simulated 'SWITCH ON FROM STANDBY' Remote Control keycode

Remote Control allows Switching on from Standby via the key `0'.
Send the code relative to key `0':

```
BE EF 02 06 00 6B E6 52 01 00 00 00 00
```

The projector switches on and the last source memorized prior to switch off is automatically selected.

Send the simulated 'MENU RIGHT' Remote Control keycode

Send the command:

```
BE EF 02 06 00 23 E7 5A 01 00 00 00 00
```

The On Screen Display appears on the screen.
The projector returns the response code:

```
06
```

which means that the command has been acknowledged with no error.

Send the 'CONTRAST DECREMENT' Operation Command

Contrast value is 60.
Send the command:

```
BE EF 1A 0C 00 58 0F 01 00 03 00 00 00 00 00 00 00 00 00 00
```

The projector returns the response code:

```
20 3B 00
```

which means:

- acknowledged with no error
- new Contrast value is now 3B = 59.

Send 'PROJECTOR STATUS' Status Command

Send the command:

```
BE EF 10 0A 00 34 B7 01 01 00 01 01 15 01 00 00 02
```

The projector returns the response code:

```
BE EF 10 13 00 .. .. 01 01 00 01 01 15 01 00 00 02 00 00 00 01 .. .. .. ..
```

which means:

- Command has been executed with success (Error bytes, 18-20, are 00 00 00)
- Projector is On (Projector Status, byte 21, is 01)

Please note that bytes marked with .. are not relevant.

THIS PAGE IS INTENTIONALLY LEFT BLANK

SIM2 Multimedia S.p.A.

Viale Lino Zanussi, 11
33170 Pordenone | Italy
Phone: +39.0434383256
Fax: +39.0434383260
Email: info@sim2.it
www.sim2.com

SIM2 USA

SIM2 USA Inc.
10216 NW 47th Street
Sunrise, FL 33351
Phone: +1 (954) 442 299
Email: sales@sim2usa.com
www.sim2usa.com

SIM2 Brionvega Co. Ltd

Room 303-304, No. 244 Liaoning Road
Shanghai 200080 | CN
Phone/Fax: +86.21.62881991
Email: infoCHINA@sim2.com

SIM2 UK

Steinway House, Worth Farm
Little Horsted, Nr. Uckfield
East Sussex TN22 5TT | UK
Phone: +44.01825.750850
Fax: +44.01825.750851
Email: info@sim2.co.uk
www.sim2.co.uk